

## WCRKARMA

# VINYL POWDER FREE DISPOSABLE GLOVE







EN ISO 374-5:2016



**T** 

Food Safe

#### **COLOUR OPTIONS**





Natural

Blue

#### **FEATURES**

- · Certified to EN ISO 374-1:2016+A1:2018/Type B
- · Certified to EN ISO 374-5:2016 Virus
- $\cdot\;$  Food safe approved
- · AQL 1.5
- · Premium quality vinyl
- Powder free
- Beaded cuff for easy donning and prevention of roll back
- · Textured fingers for additional grip
- · Latex protein free
- · Ambidextrous
- · Available in blue and natural
- · Available in sizes S-XL

#### **AVAILABLE RANGE**

PART NUMBER	COLOUR	SIZE	PACK QTY
GDV40NU0SM2	Natural	Small	100 gloves
GDV45NU0MD2	Natural	Medium	100 gloves
GDV50NU0LG2	Natural	Large	100 gloves
GDV55NU0XL2	Natural	XL	100 gloves
GDV40BU0SM2	Blue	Small	100 gloves
GDV45BU0MD2	Blue	Medium	100 gloves
GDV50BU0LG2	Blue	Large	100 gloves
GDV55BU0XL2	Blue	XL	100 gloves



#### **TEST AND CERTIFICATION**

#### Certified to

- EN ISO 374-1:2016+A1:2018/Type B
- EN ISO 374-5:2016 Virus

#### **Certified by Satra**



EN ISO 374-1:2016+A1:2018/ Type B



EN ISO 374-5:2016





#### **SPECIFICATION**

SIZE	S	М	L	XL
Weight (g)	4.0±0.3	4.5±0.3	5.0±0.3	5.5±0.3
Width (mm)	80±10	95±10	110±10	≥110
Length (mm)	≥240			
Finger thickness (mm)	0.06±0.03			
Palm thickness (mm)	0.07±0.03			
Cuff thickness (mm)	0.06±0.03			

### UNDERSTANDING DISPOSABLE GLOVES

#### Nitrile

Nitrile gloves are the most common disposable glove as they provide superior resistance to low levels of chemical and oils. Nitrile gloves are durable and provide a snug fit when worn for long durations. Nitrile holds a long shelf life, so the glove will maintain its integrity. Nitrile gloves are also latex free with 3 times more puncture resistance than a latex or vinyl glove. However they do not conform to the hand as well as latex.

#### Latex

Latex provides high levels of flexibility, so the glove will conform to the hand, which is useful for handling smaller objects. Latex gloves can cause potential allergic reactions so care needs to be taken.

#### Vinyl

Vinyl gloves are the most cost-effective option however, durability isn't as strong as latex or nitrile. Vinyl gloves are well placed for short duration use, however tend not to conform well to the hand.

#### **Poly Or Polyethylene**

Poly gloves tend to be thinner when compared to nitrile, latex and vinyl which means they are more suitable for lighter duties. Thinner gloves tend to provide greater dexterity but reduced durability.

## UNDERSTANDING CHEMICAL HAND PROTECTION

Chemical glove performance is broken into 3 categories depending on the glove's breakthrough time from a selected contamination. These 3 classifications are used in conjunction with a letter code to denote the gloves certification to AS/NZS 2161.10.2005. To assist with global harmonisation Australian Standards generally encompass European standard markings EN ISO 374:2016 outlined below:

TYPE	MINIMUM TEST DURATION	NUMBER OF CHEMICALS TESTED
А	Greater than 30 mins	6
В	Greater than 30 mins	3
С	Greater than 10 mins	1

The above information should be used in conjunction with the wearers own risk assessment, adequate knowledge of AS/NZS standards.

#### **APPLICATIONS**

Including but not limited to industries such as:

- Food preparation
- · Domestic cleaning



#### FITTING INSTRUCTIONS

Dry the hand before putting on the gloves, adjust the glove to fit the fingers, palm and wrist, take off the glove by pulling the cuff area.

#### LIMITATIONS OF USE

- · Wearer must complete a risk assessment to determine suitable protection required
- · Risk assessment must determine if glove is suitable for known contamination
- Replace gloves when glove shows signs of wear and tear
- · Designed to be SINGLE USE only
- · Dispose of gloves after use sensibly

#### STORAGE & SHELF LIFE

- · Store in a clean and dry environment
- Sunlight may cause gloves to become discoloured and lose their dexterity. Store away from direct sunlight



Bremick Pty Ltd

Head Office | 88 Dalmeny Avenue, Rosebery 2018 National Distribution Centre | M5/M7 Logistics Park, Warehouse 4B, 290 Kurrajong Road, Prestons NSW 2170