



WORKARMA

PVC SINGLE DIP 27CM

CHEMICAL RESISTANT GLOVE



Australian Standard
 AS/NZS 2161.2:2020
 AS/NZS 2161.3:2020
 Lic.SMK41346
 SAI Global



Chemical Resistant



Oil Resistant Dip



Extended Cuff



Economy

EN 388:2016



4131

FEATURES

- Certified to AS/NZS 2161.2:2020 (ISO 21420) - General Requirements and Test Methods
- Certified to AS/NZS 2161.3:2020 (EN 388) - Protection Against Mechanical Risks
- Single dipped Red PVC 27cm glove
- Light cotton interlocked liner for increased comfort and sweat absorption
- Protects against low levels of oil and grease
- Available in size L

AVAILABLE RANGE

PART NUMBER	SIZE	PACK QTY
GCPSR271LG2	Large	1 Pair

WORKARMA



PVC SINGLE DIP 27CM CHEMICAL RESISTANT GLOVE Hand Protection

TEST AND CERTIFICATION

Certified to

- AS/NZS 2161.2:2020 (ISO 21420) - General Requirements and Test Methods
- AS/NZS 2161.3:2020 (EN 388) - Protection Against Mechanical Risks

Certified by SAI Global



Australian Standard
AS/NZS 2161.2:2020
AS/NZS 2161.3:2020
Lic.SMK41346
SAI Global

EN 388:2016



4131

TEST RESULT

STANDARD	TEST DESCRIPTION	CONFORMITY
EN 388:2016 +A1:2018	Abrasion resistance: 2016	Level 4
	Cut resistance: 2016	Level 1
	Tear strength resistance: 2016	Level 3
	Puncture resistance: 2016	Level 1
EN ISO 21420:2020	pH - Textile (KCl solution)	Pass
	Azo-dyes	Pass
	Dimethylformamide	Pass
	Polycyclic Aromatic Hydrocarbons	Pass
	Dexterity	Level 5
	Dimethylfumarate (DMFu)	Pass
	XRF screening	Pass
	XRF screening (Tin)	Pass


UNDERSTANDING PROTECTION AGAINST MECHANICAL HAZARDS (EN 388:2016 +A1:2018)

Protection against mechanical hazards is symbolised by a pictogram followed by four numbers (performance levels) then two letters. For the first 4 positions the higher the number, the higher the level of protection. For the 5th position, the TDM cut test, A to F will be awarded for each gloves test result, with A being the lower score and F being the highest score. The letter P in the six position (if applicable) is for gloves certified to provide impact protection.

Example:

TEST	RATING RANGE	EXAMPLE RESULT
Abrasion	1-4	4
Cut (Coupe Test)	1-5	x
Tear	1-4	4
Puncture	1-4	2
Cut (TDM Test ISO 13997)	A-F	C
Impact protection	P	P

EN 388:2016



4X42CP

For dulling during the cut resistance test, the coupe test results are only indicative, while the TDM cut resistance test is the reference performance result. If there is an X in any of the positions, it means this performance metric was not tested.

The above information should be used in conjunction with the wearers own risk assessment, adequate knowledge of AS/NZS standards.

APPLICATIONS

Including but not limited to industries such as:

- Automotive
- Food handling
- Manufacturing
- Spill cleaning
- Petroleum refining
- Maintenance

WORKARMA



PVC SINGLE DIP 27CM CHEMICAL RESISTANT GLOVE Hand Protection

FITTING INSTRUCTIONS

Donning chemical gloves

1. Inspect for any faults
2. Wash your hands and make sure they're completely dry
3. Put on one glove at a time

Doffing your gloves

1. Rinse your gloves to reduce potential contamination to the skin. If this is not possible, be extra careful for chemical splashes
2. Pull your fingertips of one of the gloves
3. Crumple your loosened fingertips into a ball and free your hand partially
4. Using the cuff of your partially loosened glove, grip the other cuff and pull down until the second glove is inside out and over the top of your first glove
5. Use your fingertips to fully remove the chemical gloves. Pay attention not to make any contact with the contaminated side of the glove. You can either throw them into an appropriate waste bin or decontaminate them as per the below instructions

DECONTAMINATION

- Remove gloves as per the doffing instruction and immediately wash hands with soap and water
- Wash gloves in a mixture of soap and water, including the inside of the gloves
- Hang them to dry in a clean location away from direct sunlight. Make sure they are completely dry before storage
- Store the gloves in a dry, cool area, away from sunlight
- Before next use, check gloves for holes, cracks, tears, colour change and discard any glove presenting such defects
- DO NOT USE DAMAGED GLOVES

WARNINGS AND LIMITATIONS OF USE

- Wearer must complete a risk assessment to determine suitable protection required
- Risk assessment must determine if glove is suitable for known contamination.
- Replace gloves when glove shows signs of wear and tear.
- Gloves shall not be worn when there is a risk of entanglement by moving parts of machines
- Protects against low levels of oil and grease

STORAGE, SHELF LIFE AND CLEANING

- Store in a clean, dry environment with temperatures between -5°C and +45°C
- Sunlight may cause gloves to become discoloured and lose their dexterity. Store away from direct sunlight